

10 Loading postage – TELESET


TELESET is the loading of the desired postage credit via modem. The modem is integrated into the optimail 30. To load postage you dial the Teleset data center (TDC) with the optimail 30 and call the desired amount. Billing occurs according to your contract with the United States Postal Service.

Regular contact with the Teleset data center

For reasons of safety the United States Postal Service demands that the postage meter connect with the Teleset data center at regular intervals.


The optimail 30 issues a message when a contact with the Teleset data center is due. You must then start TELESET as usual. Simply load a sum of \$ 0 if you do not need any postage for the time being.

The optimail 30 will disable vital functions until a contact with the Teleset data center could be established if you fail to react to the message within an adequate period of time. Please contact the Francotyp-Postalia Service if you have any questions.



Loading postage

The optimail 30 must be connected to the telephone line for the duration of the loading process. Make sure the modem dialing properties and the Teleset data center (TDC) telephone number are set correctly.

- Press the  key.
- Select TELESET to call up the loading procedure.

- Accept the amount to be loaded

or

use CHANGE to open the menu for the amount to be loaded. Type the desired amount.

- Confirm with LOAD.



The optimail 30 checks whether the desired amount can be loaded. The optimail 30 will not accept impermissible amounts – an appropriate message appears.

To load the indicated amount:

- Use LOAD to establish the connection to the Teleset data center.

Loading continues automatically. You can monitor the progress in the display. Please stand by. Data exchange takes some time.

The new residual amount is indicated when loading ends.



Use REPORT to view and print the loading report.